

CF300 Pre-order Work Instruction

- ☕ The male/female connectors have an 13mm \varnothing gold plated pin/socket.
- ☕ The male locking sleeves are on the pin-end connectors and the female locking sleeves are on the socket-end connectors.



- ☕ Make sure the locking caps are on and seated past the 2 moulded o-rings.
- ☕ Cut 16" (406mm) of ITCSN 0800 shrink tube x 3 or 4 (if using a connector as an earth).
- ☕ From the bevel to the end of the connector wire should be 26" (660mm).
- ☕ Clean connectors with approved cleaner to remove any dirt/grime.
- ☕ Put the ITCSN 0800 over the end, slide down and stop at the bevel.
- ☕ Starting at the bevel and going towards the end of the wire, apply heat to shrink down the tubing making sure to get the full length. When complete wipe the shrink tubing down to clean as needed.
- ☕ If shipping the connectors as a loose item then proceed to packing.